

Security/Fire Panels

			Bosch
			Radionics D7000, D9000
FEATURES SUPPORTED			
1	System Configuration	Automatically Import Points	-
2		Automatically Create Events	-
3	Notification	Real-Time Status Update	Y
4		Recovery/Diagnosis Notification	-
5		Alarm Status Data Displayed in Event	-
6	Device Icons	Device Icon Blinks on Anomaly	Y
7		Tool-tip or Bubble-help	Y
8		Details Window	Y
9	Device Supports	Panel Status	Y
10		Point Status	Y
11		Arm/Disarm Areas	Y
12		Control Relay	Y

FEATURES -- DESCRIPTIONS

System Configuration

1. Automatically Import Points -- Automation to import Alarm-point panel configurations into IDE.
2. Automatically Create Events -- Optional Event auto-generation when configuring Alarm-points in IDE

Notification

3. Real-Time Status Update -- For devices configured in IDE, notification will be sent for real time status updates
4. Recovery/Diagnosis Notification -- Panel failures automatically generate System Anomaly Events containing cause symptoms
5. Alarm Status Data Displayed in Event -- Alarm Status, Alarm Type and Alarm Area will be displayed in the alarm's Event detail

Device Icons

6. Device Icon Blinks on Anomaly -- Device Icon "Blinks" when the linked device becomes anomaly (based on status).
7. Tool-tip or Bubble-help -- Linked Device's Status and will appear when the cursor is placed over the Device Icon.
8. Details Window -- Linked Device's detail information will appear when you click the Device Icon.

Device Supports

9. Panel Status -- Panel Information Support
10. Point Status -- Point Information Support
11. Arm/Disarm Areas -- Can Arm/Disarm Area from associated device icon
12. Control Relay -- Can control a relay from associated device icon